



AIRCRAFT CLEANERS & DISINFECTANTS

AERODIS® 7127



Product description: DISINFECTANT

FEATURES:

- ▶ Comes in ready-to-use spray bottles and pre-saturated towelettes
- ▶ White liquid with a citrus odor
- ▶ A water based cleaner and disinfectant



KEY BENEFITS:

- ▶ Kills over 99.9% of germs botanically, including Influenza A2, Avian Influenza a (H3N2), Hiv-1, Pseudomonas Aeruginosa (ATCC 15442), Rhinovirus Type 37, Salmonella Enterica (Salmonella Choleraesuis) (ATCC 10708), Staphylococcus Aureus (ATCC 6538), and MRSA (ATCC 33592)
- ▶ Classified as a toxicity **Category IV** (EPA's lowest concern level for acute toxicity concern. **Category IV** products are not required to have First Aid or Precautionary statements on the label.)
- ▶ Suitable for use on aircraft lavatories, galleys, windows and transparencies, tray tables, service trays, overhead bins, arm rests, head rests, vinyl walls, bulkheads, stainless steel, porcelain, floors, and any other hard surfaces on aircraft
- ▶ No rinsing or wiping is required, even on food contact surfaces
- ▶ Does not stain aircraft interiors

Rev: 20070H
12-11-2023



AIRCRAFT CLEANERS & DISINFECTANTS

AERODIS® 7127



Product description: DISINFECTANT

AeroDis® 7127 qualifies for emerging viral pathogen claims per the EPA's 'Guidance to Registrants: Process for Making Claims Against Emerging Viral Pathogens not on EPA-Registered Disinfectant Labels' when used in accordance with the appropriate use directions indicated below:

AeroDis® 7127 meets the criteria to make claims against certain emerging viral pathogens from the following viral categories:

- Enveloped viruses

SPECS:

- AMS 1550 (Meets requirements)
- AMS 1452 (Meets requirements)
- Boeing BSS7434 (S/S D6-7127) (Meets requirements)
- NSN: 6840-01-686-9908 (pre-saturated wipes)
- NSN: 6840-01-686-9917 (case of twelve 23 fl oz (680 mL) spray bottles)
- T.O.: 1-1-691 (Meets requirements)

APPLICATIONS:

- ✓ **Cleaning:** Wet the surface with **AeroDis® 7127** (spot test to check surface compatibility). For stubborn stains, let surface stand for a few minutes.
- ✓ **Sanitizing:** 1.) Wet the surface with **AeroDis® 7127** (spot test to check surface compatibility).
2.) Leave the surface for 30 seconds so that it can air-dry.
- ✓ **Disinfecting/Deodorizing:** 1.) Wet the surface with **AeroDis® 7127** (spot test to check surface compatibility).
2.) Leave the surface for 10 minutes so that it can air-dry.
- ✓ **Deodorizing:** 1.) Wet the surface with **AeroDis® 7127** (spot test to check surface compatibility).
2.) Allow surface to air-dry



AIRCRAFT CLEANERS & DISINFECTANTS

AERODIS® 7127



Product description:

DISINFECTANT

PHYSICAL PROPERTIES:

- ▶ **Appearance:** White Liquid
 - ▶ **Effect On Stressed Acrylic:** None
 - ▶ **Effect On Stressed Polycarbonate:** None
 - ▶ **Flash Point:** None
 - ▶ **Odor:** Citrus
 - ▶ **PH:** 8.5
 - ▶ **Specific Gravity:** 1.0
-

AVAILABLE PACK SIZES:

- ▶ Towelettes (Case of 100 each)-102936
- ▶ Case of 12 of 23 fl oz (680 mL) Spray Bottles-104679
- ▶ Case of 4 each Gallon (4 each of 3.8 Liter)-104665
- ▶ 5 Gallon (18.9 Liter) Pail-104666
- ▶ 55 Gallon (208 Liter) Drum-104822

 For more information contact us :
zipchem@addevmaterials.com

